

YOUR 5-STEP QUICK START GUIDE



1 Download

First go to www.roundsolutions.biz and type in "[PCB-HEDGN-R1501-PS](#)" in the search box. Then download the PingPong manual, the Bootloader App and the SourceCode examples from the download section.

See point 5 of the manual for a list of recommended development tools.



2 Power Up

Second connect PingPong to the power supply and connect it via USB to your computer. Drivers will be installed automatically. *Troubleshooting? See point 5 in the manual.*



3 Source Code

Next use the Bootloader app to load one of the 5 different source code examples.

See 6b of manual for more information.



4 Be Creative

Enjoy developing your very own IoT applications.



5 Support

Visit the Forum at www.roundsolutions.biz in the *Support* section for help, blog articles and feedback.