

AarLogic GPS 3M

1 Introduction

This application note describes the power management considerations of AarLogic GPS 3M based on SiRFstarIII single chip. Two power saving modes are described with timing diagram and estimated power consumption.

In general, the power management scheme goes as follows:

The receiver starts in the full power mode until the user's position is fixed and relevant information is gathered. In a cold start (autonomous operation), it will take about 30 to 40 seconds on average to compute the first position fix and extract other information. The time will be shorter in other cases, such as aided or hot starts.

Once the receiver is ready for normal processing, different portions of hardware can be turned off or un-clocked, depending on the receiver state. After all the processing is completed, the receiver will program the Real Time Clock (RTC) wakeup register to wake up at some time in the future, and then go to sleep by turning off most of the circuitry except the RTC. When the wakeup interrupt occurs, the receiver starts up the system and resumes GPS tasks.

2 Power Management Modes Overview

The following kinds of power saving modes are offered to meet demanding applications that have different requirements in position report interval and power consumption. These modes perform similarly in principle but provide different output rates and reliability. They are Adaptive Trickle Power and Push to Fix.

Key characteristics of power management modes are as follows:

- Adaptive Trickle Power is intended to save power by cycling between full power, a reduced power setting using just the CPU, and a low-power setting in a fixed-rate cycle. Cycle times range between 1 and 10 seconds. When signal levels are strong enough, it provides a fixed power savings and provides a constant output rate. But when signal levels drop, it returns to full power so that message output rates remain constant even in difficult environments. This results in variable power savings but much

more reliable performance for a fixed output rate. Applications using this mode should give performance very similar to full power, but with significant power savings in strong-signal conditions.

2.1 Power Management System States

Depending on different states of the power management, the receiver belongs to one of four system states.

Full power state

This is the initial state of the receiver where all RF circuitry and the baseband are fully powered. The receiver stays in this state until a position solution is made and estimated to be reliable. Even in this state, there is a difference in power consumption during acquisition mode and tracking mode. During the acquisition mode, processing is more intense, thus consuming more power.

CPU only state

This state is entered when the satellite measurements have been collected but the navigation solution still needs to be computed. The RF and DSP processing are no longer needed and can be turned off.

Stand by state

In this state, the RF section is completely powered off and the clock to the baseband is stopped. About 1 mA of current is drawn in this state for the internal core regulator, RTC and battery-backed RAM. The receiver enters this state when a position fix has been computed and reported. Typically, before shutting down the RTC wakeup register is programmed to wake up the system sometime in the future. In some cases, programming the wakeup register is kipped when an external host wakes up the receiver.

Hibernate state

This is a new feature that is introduced in SiRFstarIII. It is intended for ultra-low power consuming applications. Both the RF and the baseband are turned off, leaving only the RTC and battery-backed RAM running. In this state, less than 50 μ A of current is drawn. This state is available in Push to Fix mode only.

Pin levels of system states:

	RFPWRUP	VOUT
Full power	H	Enable
CPU only	H	Enable
Stand by	L	Enable
Hibernate	L	Disable

2.2 Adaptive Trickle Power Mode

When Adaptive Trickle Power is enabled the receiver will maximize the navigation performance. Under normal tracking conditions, Adaptive Trickle Power performs a fixed power savings, but in harsh tracking environments the receiver automatically switches to full power state to improve navigation performance. When the satellites are sorted according their signal strength, the fourth satellite determines if the transition will occur or not. Currently, the threshold is 26 dB-Hz.

When tracking, conditions return to normal (four or more satellites with C/No of 30 dB-Hz or higher), the receiver switches back to a fixed power savings. Consequently, navigation results can then be improved in harsh GPS environments at the cost of using more power.

Adaptive Trickle Power is best suited for applications that require solutions at a fixed rate as well as low power consumption and still maintain the ability to track weak signals. For this purpose SiRF recommends the use of 300 ms, 1 second or 400 ms, 2 seconds duty cycles for optimum performance.


Adaptive Trickle Power is best suited for applications where regular updates are required, and where stronger signal levels are expected. The receiver is set for a specific update period, and a specific sampling time during each period (range from 200 to 900 ms). The receiver turns to full power state for the sampling time to collect data, and then operates in stand-by state for the remainder of the update period. The next full-power state is initiated by an RTC wakeup.

Adaptive Trickle Power mode cycles through full power and stand by state. However, there are some situations where the receiver stays in full-power mode. They are:

- To collect periodic ephemeris data,
- To collect periodic ionospheric data,
- To perform RTC convergence, and
- To improve navigation result.

Timing diagrams is shown in Figure 1 based on the Trickle Power parameters of 1 second interval and 300 ms on-time. Those figures are simplified for ease of understanding and may not represent true timing.

After tracking is completed, it takes approximately 160ms to compute the navigation solution and drain the UART before going to the stand by state.



3 Software interface

Power saving mode is disabled by default. In order to enable it, there are two methods, one is to use SiRF binary protocol and another is to use Round Solutions proprietary ASCII command. For SiRF binary protocol, please refer to the document, SiRF Binary Protocol Reference Manual.

Round Solutions proprietary ASCII command

All the commands follow the syntax as below:

Command: \$PLSC,MID,Parameter...*<CKSUM>\r\n

Response: \$PLSR,MID,Valid,Parameter...*<CKSUM>\r\n

Round Solutions proprietary message:

MID	Description
200	Power management
201	Poll software version

Command data format:

Name	Value	Unit	Description
MID	200		Message ID
Mode	0..3		See Table "Power Management Modi"

OnTime	200..900	ms	Must be a multiple of 100 (if not, it is rounded up to the nearest multiple of 100). OnTime must be greater than or equal to 200 ms. Set to 0 when mode = 3.
LPInterval	1000.. 2147483000	ms	Must be an integer value greater than or equal to 1000 (i.e., 1 second). LPInterval does not need to be a multiple of 100. Set to 0 when mode = 3.
MaxAcqTime	1000.. 2147483000	ms	When Adaptive Trickle Power is enabled, MaxAcqTime (in ms) is the maximum allowable interval from the start of an Adaptive Trickle Power cycle to the time a valid position fix is obtained from navigation. If this time elapses and no fix is obtained, the receiver is deactivated for up to MaxOffTime, and when the receiver reactivates, a hot start is commanded. The integer must be in multiples of 1000 ms. The smallest allowable value is 1000 ms. The largest value is 2147483000 ms.
MaxOffTime	1000.. 1800000	ms	The longest period (in ms) for which the receiver deactivates due to the MaxAcqTime timeout. The actual deactivated period may be less if the user-specified duty cycle (OnTime / LpInterval) can be maintained. It must be a positive number. The smallest allowable value is 1000 ms. The largest allowable value is 1800000 ms (i.e., 1800 seconds, or 30 minutes.) sec 10~7200 seconds End of message termination PushToFixPeriod


Power Management Modi:

Value	Description
0	Ask receiver to send current power mode
1	Set receiver to Full power mode
2	Set receiver to Adaptive Trickle Power mode

Response data format:

Name	Value	Unit	Description
MID	200		Message ID
Valid	0..1		0: command invalid, 1: command valid
Mode	1..3		See Table3.1-3
OnTime	200..900	ms	Display when mode = 2
LPInterval	1000.. 2147483000	ms	Display when mode = 2
MaxAcqTime	1000.. 2147483000	ms	Display when mode = 2 or 3
MaxoffTime	1000.. 1800000	ms	Display when mode = 2 or 3
PushToFixPeriod	10..7200	sec	Display when mode = 3
Checksum			
<CR><LF>			End of message termination

Set receiver to Advanced Trickle Power mode with 1-second interval and 300 ms On-Time:



4 Examples

Query the power management mode

Input command: \$PLSC,200,0*0E

Output response: \$PLSR,200,1,1*03

Set to Full power mode

Input command: \$PLSC,200,1*0F

Output response: \$PLSR,200,1,1*03

Set to Adaptive Trickle Power mode

Input command: \$PLSC,200,2,300,1000,300000,30000*0E

Output response: \$PLSR,200,1,2,300,1000,300000,30000*02